


scoop

PLANTERS
INDOOR USE



scoop

PLANTERS



INDOOR USE

Scoop is delivered with the LED light pre-attached under the rim of the pot (where applicable).


It comes with a two-part inner (in black) which fits snugly inside the Scoop, and holds the planting.

Place the tub of the inner in the Scoop, and then sit the circular disc inside. The tube for the water gauge, (which is a long cylinder of polystyrene) fits in the large hole in the disc.

Now Scoop is ready for planting.
DO NOT water or plant above the inner when using the pot inside, as water may escape to the drainage hole in the base of the Scoop. For extra security you can add thin weather strip (as used for windows) around the inner to make it fit extra tightly.





OUTDOOR



INDOOR

Insert the water gauge into the tube. This will rise and lower depending on the amount of water sitting in the reservoir. The gauge, and the plastic tube, can be cut down to just above soil level if preferred. Ideally the reservoir should be just full of water, which the roots will soak up through capillary action.






scoop

PLANTERS

Light - Technical specifications



Scoop Moonlight string lights - colour change and light reduction

The string light consists of two 1.6 m LED-strings. A watertight junction box for the controller (not waterproof) and a waterproof power supply. The light is controlled with a remote (not waterproof).

Specifications for LED-string with colour change:

Article No. DF-505ORGB3OD-10MM-12V-WE

Voltage: 12V DC

Emission angle: 120 degrees

Consumption for string lights – 23 w + 4 w on power supply = 27 w

Luminous flux per meter: 540 Lm

5050 SMD – 30 /m IP 54

Service life: 50,000 hours

Power supply is CE-approved according to European standards.

It is 36 w – 12vdc. IP 66.


Producer: ClimaCare ApS, Denmark


Cleaning instructions - outdoor

- 1 Use high-pressure cleaner on the outside of Scoop planters in combination with a soft sponge on very dirty areas (not at the same time). DO NOT high pressure clean or wash the string lights and controller and power supply!
- 2 Rubber and Plastic Cleanser (the same as is used for cars). Spray onto Scoop when dry and wipe off with a soft cloth. The cleanser removes stains and gives a fresh and new surface but is seldom necessary. Or: Use basic detergent, a soft sponge and hot water. However, the above-mentioned is better.

Scoop intended for planting of trees and bushes

Scoop planters is exclusively intended for planting of trees and bushes, and not for bathing or swimming!





scoop





PLANTERS

Mounting of castors and fittings

- 1 Place Scoop upside down on for instance the wrapping.
- 2 Turn the enclosed threaded bolt up through the fitting up into the bushing in Scoop.

- 3 Push the castor up into the threaded bolt, until it clicks.

The castor stands a dynamic load of 50 kgs and a static load of 100 kgs (totally for 3 castors 150/300 kgs). Scoop weighs approx. 100-120 kgs inclusive of soil and plant.



H1